

DO'S & DON'TS - INSTALLATION

- ✓ Mark the sheets using a pencil or a steel point mark and cut along the line with a blade or hacksaw when cutting the sheets.
 - ✓ Ensure that the teeth of the cutting tool are sharp to avoid uneven edges.
 - ✓ Lay the starting row sheets at the eaves end using proper alignment of the guiding thread.
 - ✓ Provide wide ridges to avoid leakage during heavy rain.
 - ✓ Paint the purlins with high-quality primers before installing sheets.
 - ✓ Clean the sheet surface after completion of masonry work.
 - ✓ Use CAT ladders while walking on the roof to avoid dents.
 - ✓ Avoid bending the sheets sharply.
 - ✓ Use good quality non-corrosive screws for fixing the roofing sheets.
 - ✓ Use accessories that are compatible with the roofing sheets.
 - ✓ Ensure proper ventilation and sufficient sloping of the roof to avoid condensation.
-

- ✗ Do not cut the sheets with a chisel as it may result in uneven edges and deform the profile.
- ✗ Do not punch the sheets to make holes in them or allow contact with cement.
- ✗ Do not leave metal filings on the sheets.
- ✗ Do not install roof sheets during rains as handling the sheets when wet can be dangerous.
- ✗ Do not allow accumulation of dirt or bird droppings on the sheets.